

SEWAGE PUMP IMPELLER SELECTION

Joe Evans, Ph.D

The fundamental difference between a centrifugal sewage pump impeller and those of its clear water cousins is its ability to pass solid material that would normally clog the latter. What differentiates various sewage pump impellers is the method by which they accomplish this. Before we explore these differences, let's review some centrifugal impeller basics.

The figure below is that of a typical, clear water, Francis vane (*radial flow*) impeller. Its major parts -- the eye, vane leading edges, and shrouds are labeled. The vane exits can be seen between the shrouds.




Figure 1

Although the mathematics that define the operation of an impeller can be complex (it is the stuff of Bernoulli and Euler), its purpose is straight forward. An impeller is designed to impart energy to a fluid so that it will flow or, if it is already flowing, undergo some increase in its elevation or pressure. It accomplishes this by increasing the fluid's

velocity as it travels through its vanes from their leading edges, located at the eye to their exits at the periphery. The ever increasing radius of the vanes results in an increasing rotational velocity that reaches some maximum at the periphery. The resulting linear velocity of the fluid, at the vane exit, is then converted to pressure in the volute.

If one were to set out to design a typical radial vane impeller, several guidelines would be followed quite closely. For instance, the overall diameter of the impeller would closely match the volute and cut water diameters in order to reduce slippage of the pumped fluid in these areas. Also, depending upon the desired hydraulic characteristics, four or more vanes would be incorporated to smooth flow at the vane exit. And, their leading edges would be sharpened to reduce losses due to friction and turbulence.

Unfortunately, if one followed these same guidelines when designing a solids handling impeller, the outcome would be doomed to failure. Unlike the typical radial vane impeller, those designed to accommodate solids violate many of the standard design rules.

Small to medium sized sewage pumps are often referred to as non clogs and their impellers are designed to try to live up to that name. Although many factors contribute to an impeller's ability to pass solids without clogging, one of the more important is its *throughlet* size.

The throughlet is defined as the open internal passage through the impeller that, ultimately, determines the largest diameter solid that can be passed. All impellers regardless of their design have some maximum throughlet size. In order to maximize throughlet size, solids handling impellers limit the number of vanes so that the passages between them can be as large as possible. Let's take a look at some of the common sewage pump impeller designs and discuss the benefits and limitations of each.

Radial Flow Solids Handling Impellers

The various members of the radial flow impeller family include the **closed**, **open**, and **semiopen** designs. Depending upon capacity, each design may incorporate from one to four vanes. The vanes are not straight, but describe a smooth curve that begins at the impeller's eye and extends to its periphery. They may also be curved upward at their entry as in the *Francis vane* design shown in figure 1

The **closed** impeller, shown below, looks very much like an exaggerated version of the clear water impeller seen in Figure 1.



Figure 2


This particular example consists of two vanes with front and back shrouds. The shrouds of the closed impeller enclose the impeller's vane passages from the eye to the periphery and are designed to accommodate the largest possible diameter solids. The vanes themselves have large, rounded leading edges to prevent clogging by rags and stringy material that could become entangled at the vane entry. On pumps with suctions up to 12", a two vane (often referred to as a two port) design is typical while larger pumps may utilize a three or four vane design. Most closed impellers also incorporate pump out vanes on the back side of the back shroud. These small, straight vanes keep the sealing area free of debris and also reduce the

unbalanced axial forces that can occur due to back shroud's larger surface area.

The major wearing surface of the closed impeller is the area where the eye protrudes into the volute suction. Replaceable volute wear rings are used to maintain proper clearance and hydraulic efficiency. A typical rule of thumb calls for wear ring replacement when the factory set tolerance has doubled.

Very large sewage pumps often use a mixed flow impeller for low head, high flow conditions. The mixed flow design utilizes a double curvature vane that provides both radial (*centrifugal*) and axial (*lifting*) flow characteristics. Also because of their extremely large throughlets (4" and greater) these larger pumps can utilize sharpened vane leading edges for greater efficiency.

Another characteristic of the closed solids impeller is that its diameter seldom exceeds 80% of the volute cut water diameter as compared with about 92% for a standard impeller. This diameter is illustrated below and is restricted, at the expense of slippage, in order to reduce vibration and noise especially at lower flows. This larger than normal clearance also reduces clogging in the area where the impeller periphery is closest to the volute case.



CUT WATER
DIAMETER

Figure 3

Another closed design is the **single vane** impeller. On the positive side, it allows for the largest possible throughlet and since there is only one vane, there is only one leading edge and thus potential clogging at the vane entry is reduced. Unfortunately, due to its lack of symmetry, it is inherently out of balance. Unlike the multivane impeller, most cannot be trimmed and must be replaced if hydraulic conditions change. The single vane impeller also tends to produce a rather steep head-capacity curve. Although this can be useful in some applications, the flatter multivane curve generally has greater utility. The figure below is that of a *semiopen*, single vane impeller. In the closed version, the vane is enclosed by a front shroud.



Figure 4

By definition, the true **open** impeller consists of nothing more than vanes mounted to a hub that is attached to the pump shaft. They are usually seen in smaller pumps and are best suited for applications involving stringy materials. Because they are shroudless, it is less likely for material to become entrapped between the impeller and the front and rear portions of the pump case. A disadvantage is their structural weakness and, because of this, they are often strengthened by a partial shroud on the back side. If the back shroud covers the entire vane structure, the impeller is designated as **semiopen**. The figure at the top right compares the two designs.

Since one or both shrouds are missing from each design, both are prone to wear at the vane edges and must be adjusted periodically in order to maintain hydraulic efficiency.



Figure 5

Typical volute / vane clearances range from 0.020" to 0.030" and increases due to wear affect pump efficiency to a greater degree than does the eye / volute wear of the closed impeller.

The semiopen impeller, due to its lack of a front shroud, also tends to create greater unbalanced axial forces than does the closed impeller. Both pump out vanes and balance holes are often utilized to minimize these forces and prevent potential bearing damage.

Although the radial flow impeller is the work horse of the sewage pump industry, there are applications for which it is not well suited. One example is low flow applications. By virtue of its large throughlet, flow rates will always be far greater than impellers of the same diameter designed for clear fluids. For example, even a small impeller designed to pass 2" solids will create BEP (Best Efficiency Point) flows of 80 to 120 GPM. Increase solids size to 3" and the flow range increases to 400 to 700 GPM. With conventional pumps flow can be reduced by throttling the discharge; however, such a tactic is not acceptable when solids are involved. This problem is exacerbated when a low flow application is complicated by a high head requirement.

Radial Forces

When a centrifugal pump is operating, the pumped fluid exerts a force on its impeller both radially (perpendicular to the shaft) and axially (parallel to the shaft). When the pump is operating at its design point (BEP), relatively uniform pressures act upon most of the impeller's surfaces. An exception is the area about the periphery where pressures

are rarely uniform regardless of the operating point. As flow decreases (or increases), unbalanced radial forces increase and usually reach a maximum at or near shut off head. This radial thrust, as it is known, is a function of total head and the width and diameter of the impeller. Thus a high head pump with a large impeller will generate more radial thrust than a low head model incorporating a smaller impeller. By design the sewage pump impeller is unusually wide and the radial forces created can be extremely high as operation moves to either side of BEP. Depending upon the particular pump, as much as the first 30% of the entire performance curve is considered unsuitable for normal operation. High radial forces can damage a pump's rotating components and can, in some cases, create enough vibration to dislodge a submersible pump from its lift out connection.

One way of reducing the effect of radial thrust is to neutralize the force itself. The double volute pump accomplishes this by adding an internal wall to the casing that, in effect, creates two volutes. Although the double volute is found in very large sewage pumps, it is not a workable solution when small to medium sized solids handling pumps are involved.

Another method involves modifying the standard constant velocity volute by increasing the volute volume in the area about the cut water. Although this reduces efficiency by 1 to 2 %, radial forces at lower flows can be reduced by as much as 25%.

Vortex (Recessed) Solids Handling Impellers

So, is there another way to overcome the low flow, high head shortcomings of the radial flow impeller? The answer is yes but, since there is no such thing as a free lunch, there is a price to pay.

The **vortex** impeller operates quite differently than the radial flow type. Instead of imparting energy directly to the pumpage,

it creates a liquid vortex (*whirlpool*) which, in turn, imparts its energy to the pumped fluid. And, as with any multistage process, some energy is consumed by the intermediate step (in this case creation and maintenance of the vortex) and results in a lower overall hydraulic efficiency. Actual efficiency depends upon pump size and speed and can range from a low of 20% to better than 55%.

None the less, such losses can often be tolerated if the end result allows something unobtainable otherwise. And, in the case of the vortex impeller several distinct advantages are offered. An example of a vortex pump and its pumping action is illustrated below.



Figure 6

The most obvious visual difference between the vortex pump and radial flow models is that its semiopen impeller resides completely out of the volute. This feature offers the sewage pump designer three distinct advantages. First, the throughlet size can easily be made to equal that of the pump's inlet. Therefore any solid that can enter the inlet can traverse the throughlet. Second, since the pumpage traverses the throughlet via vortex action, its solids seldom come in contact with the impeller. This reduces the possibility that solids, especially stringy ones, will become entangled or clog it. For the very same reason impeller wear is minimized. Finally, due to its location above the volute, unbalanced radial forces are almost nonexistent. This allows the vortex impeller to run continuously at or near shut off head without damage.

An important application of the vortex impeller is the centrifugal grinder pump. The

grinder pump utilizes a shredder assembly to macerate large solids into a fine slurry prior to its entry into the volute. Since solids no larger than 1/8" are encountered, the volute and impeller can be designed for low flow at very high heads. Small centrifugal grinders offer flows to 40 GPM at heads to 140', while larger units offer flows to 180 GPM at heads to 170'. These pumps are well suited for low pressure sewer systems because of their ability to vary flow dynamically depending upon conditions and to run at shut off head during periods when the system is loaded to capacity.

Centrifugal Screw Impellers

The figure below illustrates another very different solids handling impeller design. The **centrifugal screw** pump is a hybrid that combines features of the positive displacement screw and the centrifugal pump.




Figure 7

More often seen in the process environment because of its low shear and NPSHR characteristics, it is becoming more common in the wastewater industry. They offer relatively high efficiencies and good solids handling capability. The head - capacity curve is quite steep but is typically non-overloading. This allows operable range

from about 10 - 125% of BEP. The portion of the screw that resides in the suction nozzle is prone to wear and is protected by a replaceable or adjustable wearing surface. Like open impeller pumps, these clearances must be adjusted periodically to maintain hydraulic efficiency. The major disadvantage of the centrifugal screw is that they tend to be quite costly when compared to other designs.

Summary

So, which impeller is the best choice for any given sewage pumping application? There is no easy answer to this question. If there were, there would not be such a broad selection from which to choose.

It can probably be said that the closed, mixed flow impeller is the most efficient and trouble free when large pumps are involved. In the case of small to medium sized pumps, however, the particular application becomes an important factor in the selection process. Although the closed Francis vane tends to be more popular, the open vane design has its own strengths under certain conditions. The vortex impeller combines the positive traits of both but does so at the expense of lower hydraulic efficiency. Yet when it comes to high head - low flow applications, its lower efficiency is hardly factored into the equation.

Several manufacturers have recognized these differences and the advantages that different impeller designs can offer in a particular application environment. For this reason they offer different impeller options for their more popular pump models. It is definitely worth considering these options when designing new sewage pumping systems. They can also often solve problems in existing installations that have undergone major changes in hydraulic conditions.



PACIFIC LIQUID & AIR SYSTEMS
PUMPS • MOTORS • CONTROLS

761 Ahua Honolulu, HI 96819
Phone 808.536.7699 Fax 808.536.8761
www.pacificliquid.com